

CHARGING

1. INSTALL CHARGING CYLINDER

HINT:


When handling the charging cylinder, always follow the directions given in the instruction manual.

- Charge the proper amount of refrigerant into the charging cylinder.
- Connect the center hose to the charging cylinder.

CAUTION:

Do not open both high and low hand valves of manifold gauge set.

- Open the valve of charging cylinder.
- Press the valve core on the side of manifold gauge and expel the air inside of the center hose.




2. INSPECT REFRIGERATION SYSTEM FOR LEAKS

- Open the high pressure hand valve and charge refrigerant.
- When the low pressure gauge indicates 98 kPa (1 kgf/cm², 14 psi) close the high pressure hand valve.
- Using a gas leak detector, check the system for leakage. If leak is found, repair the faulty component or connection.

CAUTION:

Use the refrigerant recovery/ recycling machine to recover the refrigerant whenever replacing parts.



3. INSTALL CHARGING CYLINDER

HINT:

When handling the charging cylinder, always follow the directions given in the instruction manual.

- Charge the proper amount of refrigerant into the charging cylinder.
- Connect the center hose to the charging cylinder.

CAUTION:

Do not open both high and low hand valves of manifold gauge set.

- Open the valve of charging cylinder.
- Press the valve core on the side of manifold gauge and expel the air inside of the center hose.

A fully charged system is indicated by the sight glass being free of any bubbles.

4. SET OFF MANIFOLD GAUGE SET

- Close both hand valves of manifold gauge set.
- Disconnect the quick disconnect adapters from the service valves.

5. INSTALL CAPS TO SERVICE VALVES ON REFRIGERANT LINES