

## DISASSEMBLY

### 1. REMOVE AIR REFINER FILTER

- (a) Release the 4 claws and remove the cover.
- (b) Pull out the air refiner filter.

### 2. REMOVE AIR INLET SERVOMOTOR

Remove the 3 screws and servomotor.

### 3. REMOVE BLOWER MOTOR

Remove the 3 screws and blower motor.

### 4. REMOVE BRACKET

Remove the screw and bracket.