

DISASSEMBLY

1. REMOVE COOLING FANS

Remove the 2 nuts and both fans.

2. REMOVE COOLING FAN MOTORS

- (a) Disconnect wire harness clamps.
- (b) Remove the 6 screws and both motors.