



## INSPECTION

### INSPECT ECT SWITCH

- (a) Using an ohmmeter, check that no continuity exists between the terminals when the coolant temperature is above 100 °C (212 °F).

If continuity exists, replace the switch.

- (b) Using an ohmmeter, check that continuity exists between the terminals when the coolant temperature is below 91 °C (196 °F).

If there no continuity exists, replace the switch.