

## EXPANSION VALVE

AC0X8-01

### ON-VEHICLE INSPECTION

1. CHECK QUANTITY OF GAS DURING REFRIGERATION CYCLE
2. SET ON MANIFOLD GAUGE SET  
(See page [AC-17](#))

3. RUN ENGINE

Run the engine at 1,500 rpm for at least 5 minutes.

Then check that the high pressure reading is 1.37 – 1.57 MPa (14 – 16 kgf/cm<sup>2</sup>, 199 –228 psi).

4. CHECK EXPANSION VALVE

If the expansion valve is faulty, the low pressure reading will drop to 0 kPa (0 kgf/cm<sup>2</sup>, 0 psi).