



REMOVAL

REMOVE FRONT SEAT

(a) Using a screwdriver, remove the cap.

HINT:

Tape the screwdriver tip before use.

(b) Remove the front seat outer belt floor anchor bolts and seat belt anchor.

(c) Using a screwdriver, remove the seat track covers.

HINT:

Tape the screwdriver tip before use.

(d) Remove the 4 bolts.

(e) Disconnect the connectors.

(f) Remove the front seat.

NOTICE:

Be careful not to damage the body.