

## PROBLEM SYMPTOMS TABLE

If a normal code is displayed during the DTC check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

### NOTICE:

**When replacing ABS & BA & TRAC & VSC ECU, sensor or etc., turn the ignition switch OFF.**

Symptom	Suspect Area	See page
ABS does not operate	Only when 1. to 4. are all normal and the problem is still occurring, replace the ABS & BA & TRAC & VSC ECU. 1. Reconfirm the DTC and check that the normal code is output. 2. IG power source circuit 3. Speed sensor circuit 4. Check the hydraulic brake booster with a checker or LEXUS hand-held tester. If abnormal, check the hydraulic circuit for leakage (See page <a href="#">DI-614</a> ).	<a href="#">DI-484</a>  <a href="#">DI-511</a> <a href="#">DI-497</a> <a href="#">BR-38</a>
ABS does not operate efficiently	Only when 1. to 4. are all normal and the problem is still occurring, replace the ABS & BA & TRAC & VSC ECU. 1. Reconfirm the DTC and check that the normal code is output. 2. Speed sensor circuit 3. Stop light switch circuit 4. Check the hydraulic brake booster with a checker or LEXUS hand-held tester. If abnormal, check the hydraulic circuit for leakage (See page <a href="#">DI-614</a> ).	<a href="#">DI-484</a>  <a href="#">DI-497</a> <a href="#">DI-524</a> <a href="#">BR-38</a>
ABS warning light abnormal	1. ABS warning light circuit 2. ABS & BA & TRAC & VSC ECU	<a href="#">DI-555</a> <a href="#">IN-32</a>
DTC check cannot be done	Only when 1. and 2. are all normal and the problem is still occurring, replace the ABS & BA & TRAC & VSC ECU. 1. ABS warning light circuit 2. Tc terminal circuit	<a href="#">DI-555</a> <a href="#">DI-564</a>
Speed sensor signal check cannot be done	1. Ts terminal circuit 2. ABS & BA & TRAC & VSC ECU	<a href="#">DI-566</a> <a href="#">IN-32</a>