

DTC	P0133	Oxygen Sensor Circuit Slow Response (Bank 1 Sensor 1)
------------	--------------	--

DTC	P0153	Oxygen Sensor Circuit Slow Response (Bank 2 Sensor 1)
------------	--------------	--

CIRCUIT DESCRIPTION

Refer to DTC P0125 on page [DI-43](#).

DTC No.	DTC Detecting Condition	Trouble Area
P0133 P0153	Response time for heated oxygen sensor's voltage output to change from rich to lean, or from lean to rich, is 1.1 sec. or more during idling after engine is warmed up (2 trip detection logic)	<ul style="list-style-type: none"> • Open or short in heated oxygen sensor circuit • Heated oxygen sensor • Air induction system • Fuel pressure • Injector • ECM

HINT:

- Bank 1 refers to bank that includes cylinder No.1.
- Bank 2 refers to bank that does not include cylinder No.1.
- Sensor 1 refers to the sensor closer to the engine body.

WIRING DIAGRAM

Refer to DTC P0125 on page [DI-43](#).

INSPECTION PROCEDURE

HINT:

Read freeze frame data using LEXUS hand-held tester or OBD II scan tool. Because freeze frame records the engine conditions when the malfunction is detected. When troubleshooting, it is useful for determining whether the vehicle was running or stopped, the engine was warmed up or not, the air-fuel ratio was lean or rich, etc. at the time of the malfunction.

1	Are there any other codes (besides DTC P0133 or P0153) being output?
----------	---

YES

Go to relevant DTC chart (See page [DI-13](#)).

NO

2	Check output voltage of heated oxygen sensor during idling.
----------	--

PREPARATION:

Warm up the heated oxygen sensor with the engine speed at 2,500 rpm for approx. 90 sec.


CHECK:

Use the OBD II scan tool or LECUS hand-held tester to read the output voltage of the heated oxygen sensor during idling.

OK:

Heated oxygen sensor output voltage:

Alternates repeatedly between less than 0.4 V and more than 0.55 V (See the following table).



OK

Go to step 7

NG

3

Check for open and short in harness and connector between ECM and heated oxygen sensor (See page IN-32)

NG

Repair or replace harness or connector.

OK

4

Check air induction system (See page SF-1)

NG

Repair or replace.

OK

5

Check fuel pressure (See page SF-6).

NG

Check and repair fuel pump, pressure regulator, fuel pipe line and filter (See page SF-1).

OK**6** Check injector injection (See page SF-22).**NG**

Replace injector.

OK

Replace heated oxygen sensor.

7 Perform confirmation driving pattern.**GO****8** Is there DTC P0133 or P0153 being output again?**NO**Check for intermittent problems
(See page [DI-3](#)).**YES**Check and replace ECM (See page [IN-32](#)).