


<b>DTC</b>	<b>P1300</b>	<b>Igniter Circuit Malfunction (No.1)</b>
<b>DTC</b>	<b>P1305</b>	<b>Igniter Circuit Malfunction (No.2)</b>
<b>DTC</b>	<b>P1310</b>	<b>Igniter Circuit Malfunction (No.3)</b>
<b>DTC</b>	<b>P1315</b>	<b>Igniter Circuit Malfunction (No.4)</b>
<b>DTC</b>	<b>P1320</b>	<b>Igniter Circuit Malfunction (No.5)</b>
<b>DTC</b>	<b>P1325</b>	<b>Igniter Circuit Malfunction (No.6)</b>
<b>DTC</b>	<b>P1330</b>	<b>Igniter Circuit Malfunction (No.7)</b>
<b>DTC</b>	<b>P1340</b>	<b>Igniter Circuit Malfunction (No.8)</b>

## CIRCUIT DESCRIPTION


A Direct Ignition System (DIS) has been adopted. The DIS improves the ignition timing accuracy, reduces high-voltage loss, and enhances the overall reliability of the ignition system by eliminating the distributor. The DIS is a 1-cylinder ignition system which ignites one cylinder with one ignition coil. In the 1-cylinder ignition system, the one spark plug is connected to the end of the secondary winding. High voltage generated in the secondary winding is applied directly to the spark plug. The spark of the spark plug pass from the center electrode to the ground electrode.

The ECM determines ignition timing and outputs the ignition signals (IGT) for each cylinder. Based on IGT signals, the power transistors in the igniter cuts off the current to the primary coil in the ignition coil is supplied to the spark plug that are connected to the end of the secondary coil. At the same time, the igniter also sends an ignition confirmation signal (IGF) as a fail-safe measure to the ECM.



DTC No.	DTC Detecting Condition	Trouble Area
P1300 P1305 P1310 P1315 P1320 P1325 P1330 P1340	No IGF signal to ECM while engine is running	<ul style="list-style-type: none"> <li>• Ignition system</li> <li>• Open or short in IGF1 or IGF2 and IGT1 – IGT8 circuit from ignition coil with igniter</li> <li>• No.1 – No.8 ignition coil with igniter</li> <li>• ECM</li> </ul>

## WIRING DIAGRAM



## INSPECTION PROCEDURE

### HINT:

- If DTC P1300 is displayed, check No.1 ignition coil with igniter circuit.
- If DTC P1305 is displayed, check No.2 ignition coil with igniter circuit.
- If DTC P1310 is displayed, check No.3 ignition coil with igniter circuit.
- If DTC P1315 is displayed, check No.4 ignition coil with igniter circuit.
- If DTC P1320 is displayed, check No.5 ignition coil with igniter circuit.
- If DTC P1325 is displayed, check No.6 ignition coil with igniter circuit.
- If DTC P1330 is displayed, check No.7 ignition coil with igniter circuit.
- If DTC P1340 is displayed, check No.8 ignition coil with igniter circuit.
- If DTC P1300 and P1330 are output simultaneously, IF1L circuit may be open or short.
- If DTC P1315 and P1325 are output simultaneously, IF1R circuit may be open or short.
- If DTC P1310 and P1320 are output simultaneously, IF2L circuit may be open or short.
- If DTC P1305 and P1340 are output simultaneously, IF2R circuit may be open or short.
- Read freeze frame data using LEXUS hand-held tester or OBD II scan tool. Because freeze frame records the engine conditions when the malfunction is detected. When troubleshooting, it is useful for determining whether the vehicle was running or stopped, the engine was warmed up or not, the air-fuel ratio was lean or rich, etc. at the time of the malfunction.

1

**Check spark plug and spark (See page IG-1).**

NG

**Go to step 4.**

OK

2


**Check for open and short in harness and connector in IGF and IGT signal circuits between ECM and ignition coil with igniter (See page IN-32).**

NG

**Repair or replace harness or connector.**

OK

- 3** Disconnect ignition coil with igniter connector, and check voltage between terminals IF1L, IF1R, IF2L, IF2R of ECM connector and body ground.

**PREPARATION:**

- Remove the engine room ECU cover (See page SF-81).
- Disconnect the ignition coil with the igniter connector.
- Turn the ignition switch ON.

**CHECK:**

Measure the voltage between terminals IF1L, IF1R, IF2L, IF2R of the ECM connector and body ground.

**OK:**

**Voltage: 4.5 – 5.5 V**

**OK**

Replace ignition coil with igniter.

**NG**

Check and replace ECM (See page [IN-32](#)).


- 4** Check for open and short in harness and connector in IGT signal circuit between ECM and ignition coil with igniter (See page [IN-32](#)).

**NG**

Repair or replace harness or connector.

**OK**

# 5 Check voltage between terminals IGT1 – IGT8 of ECM connector and body ground.



## PREPARATION:


Remove the engine room ECU cover (See page SF-81).

## CHECK:

Measure the voltage between terminals IGT1 – IGT8 of the ECM connector and body ground when the engine is cranked.

## OK:

**Voltage: More than 0.1 V and less than 4.5 V**



## Reference: INSPECTION USING OSCILLOSCOPE

During cranking or idling, check the waveform between terminals IGT1 – IGT8 and E1 of the ECM connector.

## HINT:


Correct waveform appears as shown, with rectangle waves.

**NG**

**Check and replace ECM (See page IN-32).**

**OK**

# 6 Disconnect ignition coil with igniter connector, and check voltage between terminals IGT1 – IGT8 of ECM connector and body ground.



## PREPARATION:

(a) Remove the engine room ECU cover (See page SF-81).

(b) Disconnect the ignition coil with the igniter connector.

## CHECK:

Measure the voltage between terminals IGT1 – IGT8 of the ECM connector and body ground when the engine is cranked.

## OK:


**Voltage: More than 0.1 V and less than 4.5 V**

**NG**

**Check and replace ECM (See page IN-32).**

**OK**

# 7 Check ignition coil with igniter power source circuit.



## PREPARATION:

Disconnect the ignition coil the with the igniter connector.

## CHECK:

Measure the voltage between terminal 1 of the ignition coil with the igniter connector and body ground when the ignition switch is turned to ON and START position.

## OK:

**Voltage: 9 – 14 V**

**OK**

**Repair ignition coil with igniter power source circuit.**

**NG**

# 8 Check for open and short in harness and connector between ignition switch and ignition coil with igniter (See page [IN-32](#)).

**NG**

**Repair or replace harness or connector.**

**OK**

**Replace ignition coil with igniter.**