

DTC	B1281 / 81	Airbag sensor assembly communication stop
------------	-------------------	--

CIRCUIT DESCRIPTION

This DTC is output when communication stops between airbag sensor assembly, combination meter ECU and tilt and telescopic ECU.

DTC No.	DTC Detecting Condition	Trouble Area
B1281/81	No communication from airbag sensor assembly more than 10 seconds.	<ul style="list-style-type: none">• Airbag sensor assembly• Wireharness

WIRING DIAGRAM

See page [DI-1160](#)

INSPECTION PROCEDURE

1	Check airbag sensor assembly.
----------	--------------------------------------

CHECK:

Check whether or not DTC is output when changing to other airbag sensor assembly.


OK:

DTC must not be output.

OK

Replace the airbag sensor assembly. (Original airbag sensor assembly is failure)

NG

2**Check wireharness.****PREPARATION:**

Disconnect the connector "C8" of airbag sensor assembly, "C12" of combination meter ECU and "T5" of tilt and telescopic ECU.

CHECK:

- Check continuity between terminals MPX1 of airbag sensor assembly and MPX2 of tilt and telescopic ECU.
- Check continuity between terminals MPX2 of airbag sensor assembly and MPX+ of combination meter ECU.

OK:

Continuity exists in wireharness of both (a) and (b), or either (a) or (b).

HINT:

If there is OPEN in wireharness of either (a) or (b), please repair it.

NG**Repair or replace wireharness.****OK****Replace the airbag sensor assembly.**