

DTC	B1150/23	Occupant Detection Sensor Malfunction
------------	-----------------	--

CIRCUIT DESCRIPTION


The occupant detection sensor circuit consists of the airbag sensor assembly and occupant detection sensor.

For details of the function of each components, see OPERATION on page RS-2.

DTC B1150/23 is recorded when a malfunction is detected in the occupant detection sensor circuit.

DTC No.	DTC Detecting Condition	Trouble Area
B1150/23	• Occupant detection sensor malfunction	<ul style="list-style-type: none"> • Occupant detection sensor • Airbag sensor assembly • Wire harness

WIRING DIAGRAM




H16901

INSPECTION PROCEDURE

1 Prepare for inspection (See step 1 on page [DI-650](#)).

2 Check wire harness (to ground).



CHECK:

For the connector (on the airbag sensor assembly side) between the occupant detection sensor and the airbag sensor assembly, measure the resistance between body ground and each of FSL+ and FSL-.

OK:


Resistance: 0 MΩ or Higher

NG

Repair or replace wire harness.

OK

3 Check wire harness (to B+).



CHECK:

- Turn the ignition switch to ON.
- For the connector (on the airbag sensor assembly side) between the occupant detection sensor and the airbag sensor assembly, measure the voltage between body ground and each of FSL+ and FSL-.

OK:


Voltage: Below 1 V

NG

Repair or replace wire harness.

OK

4 Check occupant detection sensor.



CHECK:

Without passenger on a passenger seat:

For the connector of the occupant detection sensor, connect the positive (+) lead from the ohmmeter to terminal FSL+ and the negative (-) lead to terminal FSL-, measure the resistance between FSL+ and FSL-.

OK:

Resistance: 50 kΩ or Higher

CHECK:

With passenger on a passenger seat:

For the connector of the occupant detection sensor, connect the positive (+) lead from the ohmmeter to terminal FSL+ and the negative (-) lead to terminal FSL-, measure the resistance between FSL+ and FSL-.

OK:


Resistance: Below 50 kΩ

NG

Replace seat cushion cover.

OK

5 Check airbag sensor assembly.



PREPARATION:

- Turn the ignition switch to LOCK.
- Disconnect negative (–) terminal cable from the battery, and wait at least for 90 seconds.
- Connect the occupant detection sensor connector and airbag sensor assembly connector.
- Connect negative (–) terminal cable to the battery, and wait at least for 2 seconds.

CHECK:

- Turn the ignition switch to ON, and wait at least for 20 seconds.
- Clear the DTC stored in memory (See step 5 on page [DI-650](#)).
- Turn the ignition switch to LOCK, and wait at least for 20 seconds.
- Turn the ignition switch to ON, and wait at least for 20 seconds.
- Check the DTC (See page [DI-650](#)).

OK:

DTC B1150/23 is not output.

HINT:

Codes other than code B1150/23 may be output at this time, but they are not relevant to this check.

NG

Replace airbag sensor assembly.

OK

From the results of the above inspection, the malfunctioning part can now be considered normal. To make sure of this, use the simulation method to check.