

PROBLEM SYMPTOMS TABLE

Proceed with troubleshooting of each circuit in the table below.

Symptom	Suspect Area	See page
<ul style="list-style-type: none"> • With the ignition switch in ON position, the SRS warning light sometimes lights up after approx. 6 seconds have elapsed. • SRS warning light is always lit up even when ignition switch is in the LOCK position. • With the ignition switch in ON position, the SRS warning light does not light up. 	<ul style="list-style-type: none"> • SRS warning light circuit 	DI-824
<ul style="list-style-type: none"> • DTC is not displayed. • SRS warning light is always lit up at the time of DTC check procedure. • DTC is displayed without Tc and CG terminal connection. 	<ul style="list-style-type: none"> • Tc terminal circuit 	DI-828