


Sliding Roof Control Switch Circuit

WIRING DIAGRAM



INSPECTION PROCEDURE

HINT:

If there is not the LEXUS hand-held tester, begin with STEP 2.

1 Check sliding roof control switch operation.

PREPARATION:

- (a) Connect the LEXUS hand-held tester to the DLC3.
- (b) Turn ignition switch ON and LEXUS hand-held tester main switch ON.
- (c) Select the DATALIST mode on the LEXUS hand-held tester.

CHECK:

Check that switch status (ON/OFF) changes on the screen of LEXUS hand-held tester as the sliding roof control switch of the vehicle is turned.

OK:



The switch status changes in the same way as the vehicle switch operation.

NG

Replace sliding roof gear assembly.

OK

2 Check sliding roof control switch.



104206

PREPARATION:

Remove sliding roof control switch.

CHECK:

Check continuity between terminals when switch operated.

OK:

Switch position	Tester connection	Specified condition
SLIDE OPEN	3 – 4	Continuity
SLIDE OFF	–	No continuity
SLIDE CLOSE	2 – 3	Continuity
TILT DOWN	3 – 5	Continuity
TILT OFF	–	No continuity
TILT UP	3 – 6	Continuity

NG

Replace sliding roof control switch.

OK

3

Check for open and short in harness and connectors between sliding roof gear assembly and sliding roof control switch (See page [IN-32](#)).

NG

Repair and replace harness or connector.

OK

Proceed to next circuit inspection shown in problem symptoms table (See page [DI-918](#)).