

REPLACEMENT

REPLACEMENT REQUIREMENTS

In the following case, replace the steering wheel pad, steering wheel or spiral cable.

- If the airbag has been deployed.
- If the steering wheel pad or spiral cable has been found to be faulty in troubleshooting.
- If the steering wheel pad, steering or spiral cable has been found to be faulty during the check in items (See page [RS-14](#)).
- If the steering wheel pad has been dropped.

CAUTION:

For removal and installation of the steering wheel pad, see page [SR-11](#) and [SR-17](#). Be sure to follow the correct procedure.