

INSTALLATION

Installation is in the reverse order of removal (See page [SA-36](#)).

AFTER INSTALLATION, CHECK FRONT WHEEL ALIGNMENT (See page [SA-4](#))