



FRONT LOWER BALL JOINT ON-VEHICLE INSPECTION

SAORP-01

INSPECT LOWER BALL JOINT EXCESSIVE PLAY ON-VEHICLE

- (a) Remove the tire and install the hub nuts to the disc.
- (b) Using a dial indicator, check the lower ball joint for excessive play when you push the hub nuts up and down with a force of 294 N (30 kgf, 66 lbf).

Maximum: 0.9 mm (0.035 in.)

If it is not within the specification, replace the lower ball joint.