



## INSPECTION

### INSPECT BALL JOINT FOR ROTATION CONDITION

- As shown, flip the ball joint stud back and forth 5 times, before installing the nut.
- Using a torque wrench, turn the nut continuously one turn per 2 – 4 seconds and take the torque reading on the 5th turn.

#### Turning torque:

**1.0 – 3.4 N·m (10 – 35 kgf·cm, 9 – 30 in.-lbf)**