

DISASSEMBLY

1. CHECK DRIVE SHAFT

- Check that operation of the joint is smooth within the sliding region in the axial direction.


HINT:

If a large angle is used for the cross-groove type joint, the joint will feel like it is catching, but this does not indicate an abnormality.

- Check that the boots are not cracked, damaged or leaking.
- Check that there are no scratches on the speed sensor rotor.

2. REMOVE END COVER

- Using a screwdriver, remove the end cover.




- Use bolts, nuts and washers to keep the inboard joint together.

NOTICE:

Tighten the bolt by hand to avoid scratching the flange surface.

3. REMOVE BOOT CLAMPS

Using a side cutter or pliers, remove the 4 boot clamps.




4. REMOVE INBOARD JOINT

- Place matchmarks on the inboard joint and drive shaft.

NOTICE:


Do not push the marks.

- Using a snap ring expander, remove the snap ring.



- Using SST, an extension bar and a press, press out the inboard joint from the drive shaft.

SST 09726-12023 (09726-01031)




- (d) Mount the inboard joint in a soft jaw vise.
- (e) Using a screwdriver and hammer, tap out the inboard joint cover from the inboard joint.

NOTICE:

Make sure the cage and inner race are not positioned too much to one side of the outer race.

5. REMOVE BOOTS

Remove the inboard and outboard joint boots.

**6. REMOVE NO.2 DUST DEFLECTOR**

- (a) Mount the outboard joint in a soft jaw vise.
- (b) Using a screwdriver, remove the No.2 dust deflector.

NOTICE:

Be careful not to damage the ABS speed sensor rotor.