



## INSPECTION

### INSPECT BALL JOINT FOR ROTATION CONDITION

- As shown, flip the ball joint stud back and forth 5 times, before installing the nut.
- Using a torque wrench, turn the nut continuously one turn per 2 – 4 seconds and take the torque reading on the 5th turn.

#### Turning torque:

**0.05 – 1.0 N·m (0.5 – 10 kgf·cm, 0.4 – 9 in.-lbf)**