



INSPECTION

INSPECT BALL JOINT FOR ROTATION CONDITION

- As shown, flip the ball joint stud back and forth 5 times, before installing the nut.
- Using a torque wrench, turn the nut continuously one turn per 2 – 4 seconds and take the torque reading on the 5th turn.

Turning torque:

1.0 – 2.5 N·m (10 – 25 kgf·cm, 9 – 22 in.-lbf)