

## DISASSEMBLY

### NOTICE:


When using a vise, do not overtighten it.

#### 1. MEASURE PS VANE PUMP ROTATION TORQUE

- Check that the pump rotates smoothly without abnormal noise.
- Using a torque wrench, check the pump rotating torque.

**Rotating torque:**

**0.25 N·m (2.5 kgf·cm, 2.2 in.-lbf) or less**



#### 2. REMOVE VANE PUMP PULLEY


Using SST to stop the pulley rotating, remove the pulley set nut.

SST 09960-10010 (09962-01000, 09963-01000)

#### 3. REMOVE AIR CONTROL VALVE

#### 4. REMOVE SUCTION PORT UNION

- Remove the 2 bolts and suction port union.
- Remove the O-ring from the suction port union.



#### 5. REMOVE SOLENOID VALVE

- Using SST, remove the solenoid valve.

SST 09922-10010

### NOTICE:


Use SST 09922-10010 in the direction shown in the illustration.

- Remove the O-ring from the solenoid valve.

#### 6. REMOVE FLOW CONTROL VALVE AND SPRING

#### 7. REMOVE SPRING SEAT

- Using snap ring pliers, remove the snap ring from the front housing.




- Temporarily install a bolt to the spring seat and pull it out together with the spring seat.

### HINT:

Use a bolt with diameter 6 mm (0.24 in.) and pitch 1.0 mm (0.039 in.).

- Remove the O-ring from the spring seat.



## 8. REMOVE VANE PUMP SHAFT WITH BEARING

- Using snap ring pliers, remove the snap ring from the front housing.
- Temporarily install a appropriate plate washer and the pulley set nut to the vane pump shaft.
- Using SST, pull out the vane pump shaft with the bearing. SST 09910-00015 (09911-00011, 09912-00010)

## 9. REMOVE REAR BRACKET

- Remove the 4 bolts and rear bracket.
- Remove the O-ring from the rear bracket.

## 10. REMOVE WAVE WASHER

## 11. REMOVE SIDE FRONT PLATE, CAM RING, VANE PUMP ROTOR, VANE PLATES AND SIDE REAR PLATE

- Using an extension bar and press, press out the side front plate, cam ring, vane pump rotor, vane plates and side rear plate as an assembly.
- Remove the O-ring from the side rear plate.
- Remove the cam ring, vane pump rotor and the 10 vane plates.

### NOTICE:

**Take care not to drop the vane plate.**

- Remove the shorter straight pin from the side front plate.
- Remove the 2 O-rings from the side front plate.
- Using pliers, remove the longer straight pin from the front housing.

