


DISPOSAL OF STEERING WHEEL PAD (WITH AIRBAG)

When scrapping vehicles equipped with an airbag system or disposing of a steering wheel pad (with airbag), always first deploy the airbag in accordance with the procedure described below.

If any abnormality occurs with the airbag deployment, contact the SERVICE DEPT. of TOYOTA MOTOR SALES, U.S.A., INC..

Never dispose of a steering wheel pad which has an undeployed airbag.

When disposing of a steering wheel pad with an airbag deployed in a collision, follow the same procedure given under “AIRBAG DEPLOYMENT PROCEDURE (WHEN SCRAPPING THE VEHICLE)”, part 5, DISPOSAL OF STEERING WHEEL PAD (WITH AIRBAG)” (See page [AB-93](#)).



PRECAUTIONS FOR AIRBAG DEPLOYMENT


1. The airbag produces a sizeable exploding sound when it deploys, so perform the operation out-of-doors and where it will not create a nuisance to nearby residents.
2. When deploying the airbag, always use the specified SST; SRS AIRBAG DEPLOYMENT TOOL (SST 09082-00700). Perform the operation in a place away from electrical noise.
3. When deploying an airbag, perform the operation from at least 10 m (33 ft) away from the steering wheel pad.
4. The steering wheel pad is very hot when the airbag is deployed, so leave it alone for at least 30 minutes after deployment.
5. Use gloves and safety glasses when handling a steering wheel pad with deployed airbag.
6. Always wash your hands with water after completing the operation.
7. Do not apply water, etc. to a steering wheel pad with deployed airbag.


AIRBAG DEPLOYMENT PROCEDURE (WHEN SCRAPPING VEHICLE)

HINT: Have a battery ready as the power source to deploy the airbag.


1. **DISCONNECT NEGATIVE (–) TERMINAL CABLE FROM BATTERY**

CAUTION: Work must be started after approx. 20 seconds or longer from the time the ignition switch is turned to the LOCK position and the negative (–) terminal cable is disconnected from the battery (See page [AB-2](#)).






2. **CONFIRM FUNCTIONING OF SST** (See page AB-97)
SST 09082-00700



3. **INSTALL SST**
CAUTION: Check that there is no looseness in the steering wheel and steering wheel pad.

- (a) Remove the No. 1 under cover.
- (b) Disconnect the airbag connector of the spiral cable.




- (c) Connect the SST connector to the airbag connector of the spiral cable.

SST 09082-00700

- (d) Move the SST to at least 10 m (33 ft) from the front of the vehicle.
- (e) Close all the doors and windows of the vehicle.


NOTICE: Take care not to damage the SST wire harness.

- (f) Connect the SST red clip to the battery positive (+) terminal and the black clip to the battery negative (-) terminal.



4. **DEPLOY AIRBAG**

- (a) Confirm the no-one is inside the vehicle or within 10 m (33 ft) of the vehicle.
- (b) Press the SST activation switch and deploy the airbag.
HINT: The airbag deploys simultaneously as the LED of the SST activation switch lights up.



5. DISPOSAL OF STEERING WHEEL PAD (WITH AIRBAG)

CAUTION:

- The steering wheel pad is very hot when the airbag is deployed, so leave it alone for at least 30 minutes after deployment.
 - Use gloves and safety glasses when handling a steering wheel pad with deployed airbag.
 - Do not apply water, etc. to a steering wheel pad with deployed airbag.
 - Always wash your hands with water after completing the operation.
- (a) When scrapping a vehicle, deploy the airbag and scrap the vehicle with the steering wheel pad still installed.
- (b) When moving a vehicle for scrapping which has a steering wheel pad with deployed airbag, use gloves and safety glasses.

AIRBAG DEPLOYMENT PROCEDURE (PROCEDURE FOR DISPOSAL OF STEERING WHEEL PAD ONLY)

When disposing of the steering wheel pad (with airbag) only, never use the customer's vehicle to deploy the airbag.



Remove the steering wheel pad from the vehicle and be sure to follow the procedure given below when deploying the airbag.

HINT: Have a battery ready as the power source to deploy the airbag.

1. REMOVE STEERING WHEEL PAD (See page [AB-14](#))


CAUTION:

- When removing the steering wheel pad (with airbag), work must be started after approx. 20 seconds or longer from the time the ignition switch is turned to the LOCK position and the negative (-) terminal cable is disconnected from the battery.
- When storing the steering wheel pad, keep the upper surface of the pad facing upward.



2. REMOVE STEERING WHEEL PAD CONNECTOR

Remove the connector on the steering wheel pad rear surface from the inflator cover.



3. FIX STEERING WHEEL PAD TO DISC WHEEL WITH TIRE

- (a) Install bolts with washers in the four bolt holes in the steering wheel pad.


Bolt: L 35.0 mm (1.4 in.)

M 6.0 mm

Pitch 1.0 mm

NOTICE: Tighten the bolts by hand until the bolts become difficult to turn.

Do not tighten the bolts too much.



- (b) Using a service-purpose wire harness for vehicle, tie down the steering wheel pad to the disc wheel.

Wire harness: Stripped wire harness section 1.25 mm² or more (0.002 in.² or more)

HINT: To calculate the square of the stripped wire harness section –



$$\text{Square} = \frac{3.14 \times (\text{Diameter})^2}{4}$$

CAUTION: If a wire harness which is too thin or some other thing is used to tie down the steering wheel pad, it may be snapped by the shock when the airbag is deployed, this is highly dangerous. Always use a wire harness for vehicle use which is at least 1.25 mm² (0.002 in.²).

- (c) Using 3 wire harnesses, wrap the wire harnesses at least 2 times each around the bolts installed on the left and right of the steering wheel pad.

CAUTION: Tightly wind the wire harness around the bolts so that there is no slack.

If there is slackness in the wire harness, the steering wheel pad may come loose due to the shock when the airbag is deployed, this is highly dangerous.



- (d) Face the upper surface of the steering wheel pad upward. Separately tie the left and right sides of the steering wheel pad to the disc wheel through the hub nut holes.

Position the steering wheel pad connector so that it hangs downward through a hub hole in the disc wheel.


CAUTION:

- Make sure that the wire harness is tight. It is very dangerous if looseness in the wire harness results in the steering wheel pad coming free through the shock of the airbag deploying.


- Always tie down the steering wheel pad with the pad side facing upward. It is very dangerous if the steering wheel pad is tied down with the metal surface facing upward as the wire harness will be cut by the shock of the airbag deploying and the steering wheel pad will be thrown into the air.

HINT:

- The disc wheel will be marked by airbag deployment, so use a redundant disc wheel.



4. **CONFIRM FUNCTIONING OF SST** (See page [AB-89](#))
SST 09082-00700



5. **INSTALL SST**

CAUTION: Place the disc wheel on level ground.

- (a) Connect the SST connector to the steering wheel pad connector.

SST 09082-00700

NOTICE: To avoid damaging the SST connector and wire harness, do not lock the secondary lock of the twin lock. Also, provide some slack for the SST wire harness inside the disc wheel.

- (b) Move the SST to at least 10 m (33 ft) away from the steering wheel pad tied down on the disc wheel.

6. **COVER STEERING WHEEL PAD WITH CARDBOARD BOX OR TIRES**

(Covering Method Using Cardboard Box)

Cover the steering wheel pad with the cardboard box and weigh the cardboard box down in four places with a at least 196 N (20 kgf, 44 lbf).

Size of cardboard box: Must exceed the following dimensions –


$$x = 460 \text{ mm (18.11 in.)}$$


When dimension y of the cardboard box exceeds the diameter of the disc wheel with tire the steering wheel pad is tied to –

$$x = 460 \text{ mm (18.11 in.)} + \text{width of tire}$$

$$x = 650 \text{ mm (25.59 in.)}$$

NOTICE: If a cardboard box smaller than the size specified is used, the cardboard box will broken by the shock of the airbag deployment.





(Covering Method Using Tires)

Place at least three tires without disc wheel on top of the disc wheel with tire to which the steering wheel pad is tied.

Tire size: Must exceed the following dimensions –

Width 185 mm (7.28 in.)

Inner diam. 360 mm (14.17 in.)


CAUTION: Do not use tires with disc wheels.

NOTICE: The tires may be marked by the airbag deployment, so use redundant tires.

7. AIRBAG DEPLOYMENT

- Connect the SST red clip to the battery positive (+) terminal and the black clip to the battery negative (-) terminal.
- Confirm that no-one is within 10 m (33 ft) of the disc wheel the steering wheel pad is tied to.
- Press the SST activation switch and deploy the airbag.


HINT: The airbag deploys simultaneously as the LED of the SST activation switch lights up.



8. DISPOSAL OF STEERING WHEEL PAD (WITH AIRBAG)


CAUTION:

- The steering wheel pad is very hot when the airbag is deployed, so leave it alone for at least 30 minutes after deployment.
 - Use gloves and safety glasses when handling a steering wheel pad with deployed airbag.
 - Do not apply water, etc. to a steering wheel pad with deployed airbag.
 - Always wash your hands with water after completing the operation.
- Remove the steering wheel pad from the disc wheel.
 - Place the steering wheel pad in a vinyl bag, tie the end tightly and dispose of it the same way as other general parts.




CONFIRM FUNCTIONING OF SST

When deploying the airbag, always use the specified SST:
SRS AIRBAG DEPLOYMENT TOOL.
SST 09082-00700



1. CONNECT SST TO BATTERY

Connect the red clip of the SST to the battery positive (+) terminal and the black clip to the battery negative (-) terminal.
HINT: Do not connect the yellow connector which connects with the airbag system.



2. CONFIRM FUNCTIONING OF SST

Press the SST activation switch, and confirm the LED of the SST activation switch lights up.

CAUTION: If the LED lights up when the activation switch is not being pressed, SST malfunction is probable, so definitely do not use the SST.