

## INSTALLATION

Installation is in the reverse order of removal (See page [BR-57](#)).

**AFTER INSTALLATION, CHECK SPEED SENSOR SIGNAL (See page [DI-408](#))**