

## PROBLEM SYMPTOMS TABLE

If a normal code is displayed during the DTC check but the problem still occurs, check the circuits for each problem symptom in the order given in the table below and proceed to the relevant troubleshooting page.

### NOTICE:

**When removing the ABS (& TRAC) ECU, load, sensor or etc., turn the IG switch OFF.**

Symptoms	Inspection Circuit	See page
ABS does not operate.	Only when 1. – 4. are all normal and the problem is still occurring, replace the ABS (& TRAC) ECU. 1. Check the DTC, reconfirming that the normal code is output. 2. IG power source circuit. 3. Speed sensor circuit. 4. Check the ABS (& TRAC) actuator with a checker. If abnormal, check the hydraulic circuit for leakage (See page <a href="#">DI-458</a> ).	<a href="#">DI-408</a> <a href="#">DI-441</a> <a href="#">DI-436</a> <a href="#">BR-48</a> or <a href="#">BR-54</a>
ABS does not operate efficiently.	Only when 1. – 4. are all normal and the problem is still occurring, replace the ABS (& TRAC) ECU. 1. Check the DTC, reconfirming that the normal code is output. 2. Speed sensor circuit. 3. Stop light switch circuit. 4. Check the ABS (& TRAC) actuator with a checker. If abnormal, check the hydraulic circuit for leakage (See page <a href="#">DI-454</a> ).	<a href="#">DI-408</a> <a href="#">DI-436</a> <a href="#">DI-444</a> <a href="#">BR-48</a> or <a href="#">BR-54</a>
ABS warning light abnormal.	1. ABS warning light circuit. 2. ABS (& TRAC) ECU.	<a href="#">DI-451</a>
DTC check cannot be done.	Only when 1. and 2. are all normal and the problem is still occurring, replace the ABS (& TRAC) ECU. 1. ABS warning light circuit. 2. Tc terminal circuit.	<a href="#">DI-451</a> <a href="#">DI-454</a>
Speed sensor signal check cannot be done.	1. Ts terminal circuit. 2. ABS (& TRAC) ECU.	<a href="#">DI-456</a>