

INSTALLATION

Installation is in the reverse order of removal (See page [SA-91](#)).

AFTER INSTALLATION, CHECK REAR WHEEL ALIGNMENT (See page [SA-8](#))