


DISASSEMBLY

NOTICE:

When using a vise, do not overtighten it.

1. REMOVE IGNITION KEY CYLINDER ILLUMINATION



2. REMOVE SLIDING YOKE


(a) Place matchmarks on the sliding yoke and main shaft.

(b) Remove the bolt.

3. REMOVE LOWER DUST COVER

(a) Remove the clip.

(b) Using a screwdriver, remove the dust seal from lower dust cover.



4. REMOVE COLUMN UPPER BRACKET

(a) Using a centering punch, mark the center of the 2 tapered-head bolts.

(b) Using a 4 – 5 mm (0.16 – 0.20 in.) drill, drill into the 2 tapered-head bolts.

(c) Using a screw extractor, remove the 2 tapered-head bolts.

(d) Remove the bracket.

5. REMOVE TURN SIGNAL BRACKET

Remove the 2 screws.

6. REMOVE PROTECTOR

Remove the 2 screws.

7. REMOVE CONNECTOR BRACKET

Remove the 2 bolts.

8. REMOVE TELESCOPIC LEVER SERRATED ATTACHMENT

Remove the nut and the serrated attachment.


9. REMOVE TELESCOPIC LEVER

(a) Remove the bolt, collar, lever and washer.

(b) Remove the ball and compression spring.

10. REMOVE TELESCOPIC LEVER LOCK BOLT

Install a double nut on the lock bolt, then remove the lock bolt.



11. REMOVE BREAKAWAY BRACKET

- (a) Remove the column tube stopper bolt.
- (b) Using a snap ring expander, remove the snap ring from the main shaft.
- (c) Remove the breakaway bracket from the main shaft.

NOTICE:


Be careful the spline part of the main shaft does not come loose.

12. REMOVE 2 LOCK WEDGES FROM BREAKAWAY BRACKET**13. REMOVE STEERING SHAFT THRUST STOPPER****14. REMOVE COMPRESSION SPRING**

- (a) Using a torx socket wrench, remove the torx bolt and spring.
- (b) Remove the 2 bushings from the spring.

15. REMOVE 3 TENSION SPRINGS**16. REMOVE TILT LEVER RETAINER OF TILT LEVER SIDE**

- (a) Remove the E-ring from tilt lever lock shaft.
- (b) Remove the nut from tilt steering bolt.

**17. REMOVE TILT LEVER RETAINER OF TILT SUB LEVER SIDE**


- (a) Remove the nut from the tilt steering bolt.
- (b) Using a hexagon wrench to hold the tilt memory bolt, and remove the nut.
- (c) Remove the E-ring and spacer from the tilt lever lock shaft.
- (d) Remove the collar from the tilt memory bolt.

18. REMOVE TILT PAWL, PAWL STOPPER AND TILT LEVER

Remove the bolt, nut and washer.

19. REMOVE TILT PAWL, PAWL STOPPER, TILT SUB LEVER, TILT LEVER ASSEMBLY AND TILT LEVER LOCK SHAFT

Remove the tilt lever assembly set bolt.



20. REMOVE COLUMN UPPER TUBE WITH MAIN SHAFT

- (a) Set SST, the nut (10 mm diameter, 1.25 mm pitch), plate washer (36 mm outer diameter) and bolt (10 mm diameter, 1.25 mm pitch, 50 mm length), as shown. And then remove the 2 tilt steering bolts.

SST 09910-00015 (09911-00011, 09912-00010)

(Reference)

Nut: 90170-10004


Plate washer: 90201-10201

Bolt: 91111-51050

- (b) Remove the column upper tube with main shaft from the column lower tube.

21. REMOVE TILT MEMORY BOLT

Using a hexagon wrench, remove the tilt memory bolt and square nut.



22. REMOVE MAIN SHAFT

- (a) Using SST, compress the compression spring.
SST 09950-40011 (09957-04010, 09958-04010)
- (b) Using a snap ring expander, remove the snap ring.
- (c) Remove the main shaft from the column upper tube.
- (d) Remove the compression spring, thrust collar and bearing from the main shaft.