

## STEERING WHEEL INSPECTION


SR0GQ-03

### 1. CHECK STEERING WHEEL FREEPLAY

With the vehicle stopped and tires pointed straight ahead, rock the steering wheel gently back and forth with light finger pressure.

Freeplay should not exceed the maximum.

**Maximum freeplay: 30 mm (1.18 in.)**



### 2. CHECK STEERING EFFORT

- Center the steering wheel.
- Remove the steering wheel pad. (See page [SR-11](#))
- Start the engine and run it at idle.
- Measure the steering effort in both directions.

**Reference (Maximum): 5.4 N·m (55 kgf·cm, 48 in.-lbf)**

#### HINT:

Be sure to consider the tire type, pressure and contact surface before making your diagnosis.

- Disconnect the PPS solenoid connector.
  - Measure the steering effort in both directions and check that the steering effort exceeds the reference value in (d), and that the power assist is operating. If steering effort is not heavier than (d), check the solenoid.
  - Connect the PPS solenoid connector.
  - Torque the steering wheel set nut.
- Torque: 35 N·m (360 kgf·cm, 26 ft-lbf)**
- Install the steering wheel pad.
- (See page [SR-21](#))