



## DISPOSAL

### 1. FULLY EXTEND SHOCK ABSORBER ROD

### 2. DRILL HOLE TO REMOVE GAS FROM CYLINDER

- (a) Place the shock absorber horizontally to prevent the oil from coming out.
- (b) Using a drill, make a hole on the top of the shell as shown to discharge the gas inside.

### CAUTION:

**The gas coming out is harmless, but be careful of chips which may fly up when drilling.**