



DIAGNOSTIC CODE CLEARANCE

1. Using SST, connect terminals Tc and E1 of TDCL or check connector.
SST 09843-18020
2. IG switch ON.
3. Clear the diagnostic codes stored in ECU by depressing the brake pedal 8 or more times within 3 seconds.
4. Check that the warning light shows the normal code.
5. Remove the SST from the terminals of TDCL or check connector.
6. Connect the Short Pin to check connector.

