



## DISPOSAL

1. FULLY EXTEND SHOCK ABSORBER ROD
2. DRILL HOLE TO REMOVE GAS FROM CYLINDER

Using a drill, make a hole in the cylinder, as shown to remove the gas inside.

### CAUTION:

The gas coming out is harmless, but be careful of chips which may fly up when drilling.