



DISPOSAL

1. **FULLY EXTEND SHOCK ABSORBER ROD**
2. **DRILL HOLE TO REMOVE GAS FROM CYLINDER**

Using a drill, make a hole in the cylinder, as shown to remove the gas inside.

CAUTION:

The gas coming out is harmless, but be careful of chips which may fly up when drilling.