


# Wiring diagram for Adaptronic 420 V0.3 ECU

Andy Wyatt, Adaptronic, [www.adaptronic.com.au](http://www.adaptronic.com.au)

2005-10-03



**CAUTION: DO NOT CONNECT IGNITION OUTPUTS DIRECTLY TO IGNITION COILS**  
 The ECU has no built-in igniter. A separate ignitor or transistor must be used (as shown on this diagram)  
 Damaging the ECU outputs via misconnection will void warranty

Title		
Size	Number	Revision
A4		
Date:	10-Oct-2005	Sheet of
File:	B:\Doco\User\Sources\WiringDiagram0.3\WiringDiagram.ddb	

