

INSPECTION

1. **REMOVE INSTRUMENT PANEL UNDER COVER**
(See page [BO-88](#))
2. **REMOVE ECM PROTECTOR**
 - (a) Take out the front side of the floor carpet.
 - (b) Remove the nut and ECM protector.
3. **REMOVE ECM**
 - (a) Disconnect the 6 ECM connectors.
 - (b) Remove the 2 nuts and ECM.
4. **INSPECT ECM**
(See page [DI-179](#))
5. **REINSTALL ECM**
 - (a) Install the ECM with the nut.
 - (b) Connect the 6 ECM connectors.
6. **REINSTALL ECM PROTECTOR**
 - (a) Install the ECM protector with the 2 nuts.
 - (b) Install the floor carpet.
7. **REINSTALL INSTRUMENT PANEL UNDER COVER**
(See page [BO-94](#))