


CIGARETTE LIGHTER

FROM POWER SOURCE SYSTEM (SEE PAGE 60)



SERVICE HINTS

C10 CIGARETTE LIGHTER

2-GROUN:Approx. 12 volts with ignition SW at **ACC** or **ON** position

4-GROUND:Always continuity

○ : PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
C10	30				

○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

Code	See Page	Junction Block and Wire Harness (Connector Location)
1E	20	Instrument Panel Wire and J/B No. 1 (Left Kick Panel)
1J	20	Cowl Wire and J/B No. 1 (Left Kick Panel)
3A	22	Instrument Panel Wire and J/B No. 3 (Behind the Instrument Panel Center)
3F		

▽ : GROUND POINTS

Code	See Page	Ground Points Location
IF	40	Left Kick Panel

C10 BLUE

