

# ENGINE IMMOBILISER SYSTEM

## HOW TO PROCEED WITH TROUBLESHOOTING

DI1AJ-04

Troubleshooting in accordance with the procedure on the following pages.

