

# ENGINE (1UZ-FE)

## HOW TO PROCEED WITH TROUBLESHOOTING

DI20C-01

Troubleshoot in accordance with the procedure on the following page.

