


HORN

FROM POWER SOURCE SYSTEM (SEE PAGE 62)



SERVICE HINTS

HORN RELAY

5-3 : Closed horn SW on

: PARTS LOCATION

Code	See Page	Code	See Page	Code	See Page
B5	42	H16	40 (2JZ-GE)	J18	43
C16	42	H17	38 (3UZ-FE)		
H16	38 (3UZ-FE)		40 (2JZ-GE)		

: RELAY BLOCKS

Code	See Page	Relay Blocks (Relay Block Location)
1	24	Engine Room No.1 R/B (Engine Compartment Right)
2	25	Engine Room No.2 R/B (Engine Compartment Left)

: CONNECTOR JOINING WIRE HARNESS AND WIRE HARNESS

Code	See Page	Joining Wire Harness and Wire Harness (Connector Location)
II2	52	Engine Room Main Wire and Cowl Wire (Near the Passenger Side R/B)