

REMOVAL

1. **REMOVE FRONT PERSONAL LIGHT LENS**
2. **REMOVE FRONT PERSONAL LIGHT**
 - (a) Remove the 3 screws.
 - (b) Disconnect the 2 connectors.
3. **REMOVE GARAGE DOOR OPENER SWITCH**