



## INSPECTION

### INSPECT WASHER NOZZLE

- (a) While operating the washer. Check whether the upper point where the washer fluid hits the windshield and the surge area are within the range indicated by the hatched line.

**A: Approx. 313 mm (12.32 in.)**

**B: Approx. 434 mm (17.09 in.)**

**C: Approx. 290 mm (11.42 in.)**

**D: Approx. 181 mm (7.13 in.)**

**E: Approx. 270 mm (10.63 in.)**

**F: Approx. 153 mm (6.02 in.)**

**G: Approx. 300 mm (11.81 in.)**

**H: Approx. 462 mm (18.19 in.)**

**I: Approx. 268 mm (10.55 in.)**

**J: Approx. 287 mm (11.30 in.)**

- (b) Check if the lower point where the washer fluid hits the windshield is within the range of the wiping pattern (the area of the glass which is wiped by the wiper blades).