

INSTALLATION

Installation is in the reverse order of removal (See page [BR-13](#)).

HINT:

After the installation, check and adjust parking brake pedal travel (See page [BR-11](#)).