

CIRCUIT INSPECTION

DTC	P0500/21,23	Vehicle Speed Sensor Circuit
------------	--------------------	-------------------------------------

CIRCUIT DESCRIPTION

2JZ–GE Engine: See page [DI-108](#).

3UZ–FE Engine: See page [DI-281](#)

DTC No.	Detection Item	Trouble Area
P0500/21, 23	Speed signal is not input to the ECM while cruise control is set.	<ul style="list-style-type: none"> • Combination meter • Harness or connector between ECM and vehicle speed sensor • Vehicle speed sensor • ECM

WIRING DIAGRAM

2JZ–GE Engine: See page [DI-108](#).

3UZ–FE Engine: See page [DI-281](#)

INSPECTION PROCEDURE

2JZ–GE Engine: See page [DI-108](#).

3UZ–FE Engine: See page [DI-281](#)