


## Jam protection pulse switch circuit

### CIRCUIT DESCRIPTION

Jam protection pulse switch is built-in the power window motor. Pulse switch outputs ON/OFF pulse when the motor rotates.

### WIRING DIAGRAM



I03214

**INSPECTION PROCEDURE**

<b>1</b>	<b>Check jam protection pulse switch. (See page <a href="#">BE-123</a>)</b>
----------	---

**NG****Replace the power window motor.****OK**

<b>2</b>	<b>Check wireharness and connector between jam protection pulse switch and driver door ECU.</b>
----------	---

**NG****Repair or replace wireharness or connector.****OK**

**Proceed to next circuit inspection shown on  
problem symptoms table.  
(See page [DI-1013](#))**