

## 10. Sound of radio, cassette tape or CD only cannot be heard from speaker.

### INSPECTION PROCEDURE

1	Check the radio receiver assembly.
---	------------------------------------

**PREPARATION:**

Disconnect the radio receiver assembly connector.

**CHECK:**

Check voltage terminals +B.

**OK:**

**+B: 10 – 14 V**

**CHECK:**

Check voltage terminal ACC when turn ignition switch ACC or ON position.

**OK:**

**ACC: 10 – 14 V**

**CHECK:**

Check continuity terminal GND.

**OK:**

**GND: Continuity**

**NG**

**Replace or repair wire harness or connector.**

**OK**

**Replace the radio receiver assembly.**