

18. Panel Switch Does Not Function (A/C control only)

INSPECTION PROCEDURE

1 Display check mode (Panel Switch Check screen).

NG

Replace the multi display.

OK

2 Check "AVC-LAN communication circuit" (See page [DI-1291](#)).

NG

Replace or repair AVC-LAN circuit.

OK

3 Check multiplex communication circuit (See page [DI-1110](#)).

NG

Replace or repair multiplex communication circuit.

OK

Replace A/C amplifier.