



TERMINALS OF ECU

Body NO.1 ECU and Body NO.2 ECU




I04354

Driver Door ECU and Passenger Door ECU




I03225

Tilt and Telescopic ECU



I04355

Rear Right Door ECU and Rear Left Door ECU




(*1): Rear left door ECU
 (*2): Rear right door ECU


I03226

ECM

2JZ-GE:



3UZ-FE:




Y


I04347
 A14471

I21072


A/C Amplifier




I04359

Combination Meter ECU

I04357

Power Seat ECU

I04356

Sliding Roof ECU

I04348

