


Jam protection pulse switch circuit

CIRCUIT DESCRIPTION

Jam protection pulse switch is built-in the power window motor. Pulse switch outputs ON/OFF pulse when the motor rotates.

WIRING DIAGRAM



I03214

INSPECTION PROCEDURE

1	Check jam protection pulse switch. (See page BE-123)
----------	---

NG**Replace the power window motor.****OK**

2	Check wireharness and connector between jam protection pulse switch and passenger door ECU.
----------	--

NG**Repair or replace wireharness or connector.****OK**

**Proceed to next circuit inspection shown on problems symptoms table.
(See page [DI-1047](#))**