


# VEHICLE SKID CONTROL (VSC) & BRAKE ASSIST (BA) SYSTEM

## HOW TO PROCEED WITH TROUBLESHOOTING

DI285-06

Troubleshoot in accordance with the procedure on the following pages.



Fail safe function:

When a failure occurs in the BA & TRAC & VSC system, the VSC warning light is lit and the BA & TRAC & VSC operation is prohibited.