


























# STEERING














## SST (Special Service Tools)

PP0SM-03







	09023-12700 Union Nut Wrench 17mm	Power steering fluid
	09023-38200 Union Nut Wrench 12mm	PS gear
	09238-47012 Water Pump Bearing Remover & Replacer	PS vane pump (3UZ-FE)
	09608-04031 Front Hub Inner Bearing Cone Replacer	PS vane pump (2JZ-GE)
	09612-00012 Rack & Pinion Steering Rack Housing Stand	PS gear
	09616-00011 Steering Worm Bearing Adjusting Socket	PS gear
	09631-10030 Oil Seal Remover	PS vane pump
	09631-12071 Steering Rack Oil Seal Test Tool	PS gear
	09631-20060 Bearing Guide Nut Wrench	PS gear
	09631-20081 Seal Ring Tool	PS gear
	09631-20090 Cylinder End Stopper Nut Wrench	PS gear
	09631-20102 Steering Rack Cover "H"	PS gear

## PREPARATION – STEERING

	09640-10010 Power Steering Pressure Gauge Set	
	(09641-01010) Gauge Assy	Power steering fluid
	(09641-01030) Attachment B	Power steering fluid
	(09641-01060) Attachment E	Power steering fluid
	09910-00015 Puller Set	
	(09911-00011) Puller Clamp	PS vane pump (3UZ-FE)
	(09912-00010) Puller Slide Hammer	PS vane pump (3UZ-FE)
	09922-10010 Variable Open Wrench	PS vane pump PS gear
	09950-50012 Puller C Set	
	(09951-05010) Hanger 150	Power tilt and power telescopic steering column
	(09952-05010) Slide Arm	Power tilt and power telescopic steering column
	(09953-05020) Center Bolt 150	Power tilt and power telescopic steering column
	(09954-05020) Claw No.2	Power tilt and power telescopic steering column

	09950-60010 Replacer Set	
	(09951-00180) Replacer 18	PS vane pump (3UZ-FE) PS gear
	(09951-00260) Replacer 26	PS gear
	(09951-00280) Replacer 28	PS gear
	(09951-00300) Replacer 30	PS vane pump (3UZ-FE)
	(09951-00320) Replacer 32	PS gear
	(09951-00330) Replacer 33	PS vane pump (2JZ-GE) PS gear
	(09951-00360) Replacer 36	PS gear
	(09951-00420) Replacer 42	PS gear
	(09951-00490) Replacer 49	PS gear
	(09952-06010) Adapter	PS vane pump (3UZ-FE) PS gear
	09950-70010 Handle Set	
	(09951-07100) Handle 100	PS vane pump PS gear

## PREPARATION – STEERING

	(09951-07150) Handle 150	PS gear
	(09951-07200) Handle 200	PS gear
	(09951-07360) Handle 360	PS gear
	09960-10010 Variable Pin Wrench Set	
	(09962-01000) Variable Pin Wrench Arm Assy	PS vane pump
	(09963-01000) Pin 10	PS vane pump