


ENGINE COOLANT TEMPERATURE (ECT) SENSOR COMPONENTS

SF005-01



◆ Non-reusable part

B02006