


# LIQUID CRYSTAL INNER REAR VIEW MIRROR

FROM POWER SOURCE SYSTEM (SEE PAGE 56)



## SERVICE HINTS

### D 4 DAY/NIGHT SHIFT SW

1 – GROUND: ALWAYS APPROX. 12 VOLTS

### I15 UNLOCK WARNING SW [IGNITION SW]

10–9: CLOSED WITH IGNITION KEY IN CYLINDER

## ○ : PARTS LOCATION

CODE	SEE PAGE	CODE	SEE PAGE	CODE	SEE PAGE
D 4	30	I15	29		

## ○ : RELAY BLOCKS

CODE	SEE PAGE	RELAY BLOCKS (RELAY BLOCK LOCATION)
2	19	ENGINE COMPARTMENT LEFT

## ○ : JUNCTION BLOCK AND WIRE HARNESS CONNECTOR

CODE	SEE PAGE	JUNCTION BLOCK AND WIRE HARNESS (CONNECTOR LOCATION)
1B	20	ENGINE ROOM MAIN WIRE
1F	20	ROOF WIRE
1H		
1I	20	COWL WIRE
1J		

## ▽ : GROUND POINTS

CODE	SEE PAGE	GROUND POINTS LOCATION
IF	36	LEFT KICK PANEL

## ○ : SPLICE POINTS

CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS	CODE	SEE PAGE	WIRE HARNESS WITH SPLICE POINTS
B 2	40	ROOF WIRE			

D 4

I15 BLACK

